



7 6 5 4 3 2 1 0 1 2 3 4 5 6 7

	FRESNEL SPOT		Source four 26		HOUSE _{SPTRAKE}	KEY Channel Instrument Type Color Purpose GOBO IRIS	 세종음악창작소 Sejong Creative Center 조명도면 MEMO
	Source four 36		Source four 15-30		WASH _(16Ch)		
	Source four 50		Source four 25 - 50		MOVING SPOT _(23CH)		